# DIMAC

# T Series NC Twin Roll Feeding Machine

MODEL **720/730** 





# MODEL **TJ06/TJ15**







# T series features

- By setting the feeder on the left and right, it is possible to use it in seat mode and coil mode.
   (Steel sheet material, Steel coil material)
- Space saving design which integrates machine body and control equipment.
- Adjustment to inside and outside of bolster is possible by standard equipment of slide type plate. (Manual operation)
- The T20 / T30 adopts a C type frame, and material input can be taken from the front of the main body.
   (TJ06 / TJ15 is impossible)
- The controller will calculate the feeding rate according to "Feed Angle" and "SPM".



# **Product specifications**





Max. Material width	~ 200mm		
Waxi Waterial Water	~3.2mm		
Max. Material thickness	- 0.211111		
	∼ 200spm		
Max. Stamp speed	2003β/11		
	200V ±10% 50/60Hz		
Required power supply	3-phase / Single phase 200V ± 10% 50/60Hz		
	15kg		
Max. material transport weight	TONG		
	118mm		
Min. Pass line height	110111111		
	210mm		
Depth length from roll center			



# Model **730**

	~ 300mm	
Max. Material width	000111111	
	~ 3.2mm	
Max. Material thickness	0.211111	
	~ 200spm	
Max. Stamp speed		
	200V ±10% 50/60Hz	
Required power supply	3-phase / Single phase 200V ± 10% 50/60Hz	
	15kg	
Max. material transport weight	iong	
	118mm	
Min. Pass line height	11011111	
	260mm	
Depth length from roll center		


- \*1
  - Steel sheet material
  - In case of installing in the bolster inner side.




# **Control panel display function**

# 450C Controller

# Sheet mode







# **Product specifications**





	~70mm	
Max. Material width	7611111	
	~ 1.2mm	
Max. Material thickness	1.2111111	
	a : 200anm	
Max. Stamp speed	∼ 200spm	
	200V ±10% 50/60Hz	
Required power supply	3-phase / Single phase 200V ± 10% 50/60Hz	
	El	
Max. material transport weight	5kg	
	00000	
Min. Pass line height	83mm	
	115mm	
Depth length from roll center		





# Model **TJ15**

	~ 150mm	
Max. Material width	- 13011111	
	~ 2.3mm	
Max. Material thickness	2.311111	
	a. 200cpm	
Max. Stamp speed	~ 200spm	
	200V ±10% 50/60Hz	
Required power supply	3-phase / Single phase 200V $\pm$ 10% 50/60Hz	
	15kg	
Max. material transport weight	iskg	
	103mm	
Min. Pass line height	10311111	
	170mm	
Depth length from roll center		

Steel sheet material

In case of installing in the bolster inner side.



# **Controller options**

# DS6

Feed direction



• To change the feed direction of the feeder.

# MP6

Date bank



 To memorize the feed setting value. (Up to 20 layers)

Multiple feed is possible by combining memorized layers.

### FF6

Feed completion output



 To output a signal when the feeder finishes feeding material.

# BF6

Feed-durig output



· To output a signal when the feed-during.

# RC6

Remote box



• To remotely controls of 1 Stroke feed, Inching feed, Clamp Open / Close.



# **Feed Performance Table**

TJ06			
Feed angle Setting value	150°	180°	210°
SPM	Feed length (mm)		
200	21	31	45
180	26	40	56
160	34	52	73
140	47	70	97
120	66	97	136
100	97	144	200
80	157	231	318
60	288	408	528
40	588	769	949
20	*999	*999	*999

1315			
Feed angle Setting value	150°	180°	210°
SPM			
OI 111	Feed	d length (	mm)
200	20	31	44
180	26	39	56
160	34	51	72
140	46	69	96
120	65	96	134
100	96	142	197
80	155	228	314
60	285	403	522
40	582	760	939
20	*999	*999	*999

T20 / T30			
Feed angle Setting value	150°	180°	210°
SPM	Гоо	l longith (	
		l length (	
200	14	22	31
180	18	28	39
160	24	36	51
140	32	48	68
120	45	68	94
100	68	100	138
80	109	160	221
60	200	283	367
40	409	534	659
20	*999	*999	*999

\*

Maximum value of setting

# Precautionary Remarks on Instllation

- For the product details and installation conditions, refer to the specifications of separate sheet.
- · The control panel is English and sign only.
- When this machine is exported, make sure that the machine is provided with safeguards required in the destination country.

Example:The electric power supply to this machine is 3-phase / Single-phase 200V $\pm$ 10% · 50/60Hz. Not available option which suited the local power supply.

- Specifications in this catalog are subject to change for machine improvements without prior notice.
- · Before using the machine, read the safety instruction in the instruction manual.

VENDAR via E. Mattei 58 35020 Sant'Angelo di Piove (PD) P.iva IT05512270280